

# Fume Eliminator 840/841

Fume Eliminator 840/841 is a small, lightweight, portable extraction unit designed to be carried to the working area. Connected to a welding torch or to an extraction nozzle, the FE 840/841 unit extracts the fume directly at source. FE 840 has a manual start/stop function. FE841 has an automatic start/stop function which starts the unit as soon as the welding begins. It also includes an indicator for filter exchange.



- Portable, easy to carry
- Low service costs

	Voltage, V	Power, W (Hp)	Airflow with 2.5 m (8 ft.) hose, m <sup>3</sup> /h (cfm)	Filtration efficiency, %	Max. vacuum, kPa (in. w.g.)	Noise level, dB(A)	Length, mm (in.)	Width, mm (in.)	Height, mm (in.)	Weight, kg (lb.)	Part no.
<b>FE 840</b> Manual start/stop	120	1000 (1.3)	150 (88)	99.7	22 (88)	73	830 (33)	230 (9)	410 (16)	16 (35)	70840125
<b>FE 841</b> Auto start/stop	120	1000 (1.3)	150 (88)	99.7	22 (88)	73	830 (33)	230 (9)	410 (16)	16 (35)	70841125

	Part no.
Nozzle TM 80, length 500 mm (20 in.), Ø 80 mm (3 in.)	70851000
Nozzle TM 200, length 570 mm (22 in.), slot width 200 mm (8 in.), slot height 30 mm (1 in.)	70854000
Nozzle TM 300, slot width 300 mm (12 in.), slot height 5 mm (2 in.)	70853000
Hose, Ø 45 mm (1 3/4 in.), 5 m (16.5 ft.)	70400026
Hose, Ø 45 mm (1 3/4 in.), 15 m (50 ft.)	70400028
Replacement filter for Fume Eliminator 840 and 841	70324000

Product availability may differ by country